

## Fire Rated 093V Expansion

093X-V is a composite control joint with intumescent tape factory applied to the back side of the control joint. 093X-V has been tested according to UL-2079 "Test for Fire Resistance of Building Joint Systems" and is used to relieve stresses of expansion and contraction of drywall interior partitions or ceilings running in a horizontal or vertical direction in both metal or wood framing on one side or both sides of the wall. 093X-V is pink in color to quickly indicate fire rated materials and features a co-extruded flexible PVC center that is designed to provide a full 3/8" of protection against the stresses of expansion and contraction.

## Installation Instructions

Before installation, ensure that the wall is built to outlined specifications for XHBN.WW-D-0172 in the UL directory.

- Step 1:** Measure and cut the bead to length. Dry fit to test proper cut.
- Step 2:** Spray the bead and edge of drywall with 1 coat each of Trim-Tex 847 Spray Adhesive and position the bead into place.
- Step 3:** Once in position, pressure the leg using a Trim-Tex installation tool or the handle of your taping knife.
- Step 4:** Staple the mud leg into place every 6"-8" with 1/2" long staples.
- Step 5:** Mud as usual. Be sure to use All-Purpose or Multi-Purpose Compound. Add Mud-Max to your drywall compound for extra durability.
- Step 6:** Remove protective strips before sanding. Prime and paint as usual.

