

Cleaning a Credit Card Chip Reader

Chip card readers require regular cleaning to maintain a long life. Credit cards are filthy and inserting cards into a machine will over time deposit gunk on the chip card reader

Locate your waffle cleaning card, any brand will work



These are available at most office supply stores or at [amazon.com](https://www.amazon.com)

Google [Waffletechnology-Smart-Reader-Cleaning](https://www.google.com/search?q=Waffletechnology-Smart-Reader-Cleaning)

Recommended Usage: Once per week for internal or low usage Card Readers. Clean more frequently for external or high usage Card Readers, especially in areas prone to an abundance of grease, food particles and dust.

Usage Directions:

1. Insert the Waffletechnology Cleaning Card into smart card reader 5-6 times, in the same manner you would a regular credit card.
2. Remove card from reader, repeat step 1 if necessary.
3. Dispose of properly.