



DECORAN CARE SHEET

Decoran™ is a locally manufactured solid surface material, with an Acrylic Modified Polyester base, which combines to produce a durable, chemical resistant and non-porous product, ideal for use in homes, offices and many other applications.

BASIC DECORAN™ CARE DOs & DON'Ts

DO use trivets or hot mats under hot dishes or cookware. Repeatedly placing extremely hot items on your countertop may result in damage to the surface.

DO use a cutting board. A Decoran™ surface can be scratched or gouged if used as a cutting/chopping surface. While it can be repaired, we highly recommend the use of a cutting board to avoid the problem.

DO ensure that you run water in the sink before pouring boiling water, as this will prevent small surface fissures from forming due to temperature extremes.

DON'T use abrasives of any kind on your Decoran™ surface. This is not because the cleaner will affect the material, but because it will destroy the glossy finish of the countertop (see further information below).

CLEANING YOUR DECORAN™ SURFACE

Most common household cleaners are safe for use on Decoran™ solid surfaces. Any chemical cleaners can be used, for example, ammonia, strong detergents, acidic solutions (including Muriatic acid), Clorox and LimeAway.

If using an acidic cleaner, it is not recommended that the substance is allowed to sit on the surface for an extended period of time.

REFINISHING

We guarantee that your DECORAN countertop can last a lifetime. However, in the event of any superficial damage occurring to your countertop, we can refinish it and restore it to its original 'showroom' look.

To maintain a glossy finish on your counter, the use of Countertop Magic is recommended. This product is formulated for food contact areas and can be obtained locally at Fiberpol, Massy or Carters.

