

## Locate and Install Kodiak 'Rubber-Duck' Antennas

- Every Kodiak comes with (2) Kodiak antennas in the accessory carton that ships alongside your Kodiak Computer.
- The Kodiak Antennas are located in a small black bubble bag and may be packed in a clear zippered poly bag with a power cable or USB cable, if ordered. (Pictured, Left)
- Remove the antennas and gently mount them (hand tighten only) on the threaded connectors at the top of the computer.

