

**Legenda**

PAR = Parameters

ATT = Check Components

COD = Adaptation &amp; Coding

DIAG = Available for diagnosis

■ = supported function

A = Auto detected/recognized function

# Rolls Royce AG

## Ghost (RR4)

<b>DESCRIZIONE</b>	<b>DIAG</b>	<b>PAR</b>	<b>ATT</b>	<b>COD</b>
Active cruise control	■	■	A	A
Crash safety module	■	■	A	A
Amplifier	■	■	A	A
Rear passenger's side seat module	■	■	A	A
Front passenger seat module	■	■	A	A
Car access system	■	■	A	A
Coachdoor module	■	■	A	A
Central information display	■	■	A	A
Rear-compartment display	■	■	A	A
Rear-compartment display 2	■	■	A	A
Dynamic stability control	■	■	A	A
Telematic communication box	■	■	A	A
Electronic transmission control	■	■	A	A
Electronic height control	■	■	A	A
Fuel-pump control	■	■	A	A
Parking brake	■	■	A	A
Rear driver seat module	■	■	A	A
Driver seat module	■	■	A	A
Footwell module	■	■	A	A
Roof function centre	■	■	A	A
Gear selector switch	■	■	A	A
Rear-lid module	■	■	A	A
Head-up display	■	■	A	A
Integrated chassis management	■	■	A	A
Vertical dynamics management	■	■	A	A
Junction-box electronics	■	■	A	A
Camera-based driver assist system	■	■	A	A
Automatic heating/air conditioning	■	■	A	A
Rear-compartment air conditioning	■	■	A	A
Instrument cluster	■	■	A	A
Dvd changer	■	■	A	A
Navigation and radio module	■	■	A	A
Engine control module	■	■	A	A
Engine control module 2	■	■	A	A

Night vision electronics			A	A
Park distance control			A	A
Tyre pressure control			A	A
Damper satellite rear left			A	A
Damper satellite rear right			A	A
Damper satellite front left			A	A
Damper satellite front right			A	A
Rear seat entertainment system			A	A
Steering column switch centre			A	A
Combox multimedia			A	A
Allround-view camera			A	A
Video module			A	A
Controller			A	A
Rear-compartment controller			A	A
Central gateway module			A	A

## Phantom (RR1)

<b>DESCRIZIONE</b>	<b>DIAG</b>	<b>PAR</b>	<b>ATT</b>	<b>COD</b>
Audio Display Panel				
Audio Display Panel Rear				
Amplifier				
Tuner antenna				
Audio System Controller				
Rear seat module passenger				
Seat module passenger				
Armrest command rear center				
Control unit center console				
Car Access System				
CD changer				
Display rear 2				
Display rear				
Display rear 2^ Version				
Chassis integration				
Capote Cabrio module				
Digital radio terrestrial				
Dynamic stability control EHB3				
Alarm system				
Controller rear				
Controller				
Dampers electronic adjusting				
Gearbox module				
1-Axle air suspension				
Parking brake				
Rear seat module passenger				
Seat module driver				
Bus-Interface flessibile				
Tailgate lift				
Heater/Climate				
Control Radiator Image				
Headphone interface				

Instrument cluster				
Light module				
Display Control Gateway				
DVD Changer				
Rear display gateway				
Display Control				
Rear display				
DME - Gasoline engine management Bank 2				
DME - Gasoline engine management Bank 1				
Navigation system				
Park Distance Control				
Power module				
Tire pressure monitoring				
Sensor Daytime running lights/rain				
Satellite A pillar left				
Satellite A pillar right				
Digital radio terrestrial USA				
Satellite B pillar left				
Satellite B pillar right				
Sunroof module				
Additional control unit 1				
Satellite vehicle centre				
Safety information module				
Siren and sensor altitude changes				
Satellite passenger seat				
Satellite driver seat				
Satellite rear seat				
Satellite front left door				
Satellite front right door				
Language processing module				
Steering module				
Telephone ECE or USA / Telematic Control Unit				
Door module passenger rear				
Door module passenger				
Door module driver rear				
Door module driver				
Video module or Hybrid video module				
Valvetronic bank 1				
Valvetronic bank 2				
Wiper module				
Gateway module				

## Phantom Coupe (RR3)

<i>DESCRIZIONE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Audio Display Panel				
Audio Display Panel Rear				
Amplifier				
Tuner antenna				
Audio System Controller				
Rear seat module passenger				

Seat module passenger					
Armrest command rear center					
Control unit center console					
Car Access System					
CD changer					
Display rear 2					
Display rear					
Display rear 2^ Version					
Chassis integration					
Capote Cabrio module					
Digital radio terrestrial					
Dynamic stability control EHB3					
Alarm system					
Controller rear					
Controller					
Dampers electronic adjusting					
Gearbox module					
1-Axle air suspension					
Parking brake					
Rear seat module passenger					
Seat module driver					
Bus-Interface flessibile					
Tailgate lift					
Heater/Climate					
Control Radiator Image					
Headphone interface					
Instrument cluster					
Light module					
Display Control Gateway					
DVD Changer					
Rear display gateway					
Display Control					
Rear display					
Gasoline engine management Bank 2					
Gasoline engine management Bank 1					
Navigation system					
Park Distance Control					
Power module					
Tire pressure monitoring					
Sensor Daytime running lights/rain					
Satellite A pillar left					
Satellite A pillar right					
Digital radio terrestrial USA					
Satellite B pillar left					
Satellite B pillar right					
Sunroof module					
Additional control unit 1					
Satellite vehicle centre					
Safety information module					
Siren and sensor altitude changes					
Satellite passenger seat					
Satellite driver seat					

Satellite rear seat					
Satellite front left door					
Satellite front right door					
Language processing module					
Steering module					
Telephone ECE or USA / Telematic Control Unit					
Door module passenger rear					
Door module passenger					
Door module driver rear					
Door module driver					
Video module or Hybrid video module					
Valvetronic bank 1					
Valvetronic bank 2					
Wiper module					
Gateway module					

## Phantom Drophead Coupe (RR2)

<b>DESCRIZIONE</b>	<b>DIAG</b>	<b>PAR</b>	<b>ATT</b>	<b>COD</b>
Audio Display Panel				
Audio Display Panel Rear				
Amplifier				
Tuner antenna				
Audio System Controller				
Rear seat module passenger				
Seat module passenger				
Armrest command rear center				
Control unit center console				
Car Access System				
CD changer				
Display rear 2				
Display rear				
Display rear 2^ Version				
Chassis integration				
Capote Cabrio module				
Digital radio terrestrial				
Dynamic stability control EHB3				
Alarm system				
Controller rear				
Controller				
Dampers electronic adjusting				
Gearbox module				
1-Axle air suspension				
Parking brake				
Rear seat module passenger				
Seat module driver				
Bus-Interface flessibile				
Tailgate lift				
Heater/Climate				
Control Radiator Image				
Headphone interface				

Instrument cluster				
Light module				
Display Control Gateway				
DVD Changer				
Rear display gateway				
Display Control				
Rear display				
Gasoline engine management Bank 2				
Gasoline engine management Bank 1				
Navigation system				
Park Distance Control				
Power module				
Tire pressure monitoring				
Sensor Daytime running lights/rain				
Satellite A pillar left				
Satellite A pillar right				
Digital radio terrestrial USA				
Satellite B pillar left				
Satellite B pillar right				
Sunroof module				
Additional control unit 1				
Satellite vehicle centre				
Safety information module				
Siren and sensor altitude changes				
Satellite passenger seat				
Satellite driver seat				
Satellite rear seat				
Satellite front left door				
Satellite front right door				
Language processing module				
Steering module				
Telephone ECE or USA / Telematic Control Unit				
Door module passenger rear				
Door module passenger				
Door module driver rear				
Door module driver				
Video module or Hybrid video module				
Valvetronic bank 1				
Valvetronic bank 2				
Wiper module				
Gateway module				

## Wraith (RR5)

<b>DESCRIZIONE</b>	<b>DIAG</b>	<b>PAR</b>	<b>ATT</b>	<b>COD</b>
Active cruise control			A	A
Crash safety module			A	A
Amplifier			A	A
Rear passenger's side seat module			A	A
Front passenger seat module			A	A

Car access system				A	A
Coachdoor module				A	A
Central information display				A	A
Rear-compartment display				A	A
Rear-compartment display 2				A	A
Dynamic stability control				A	A
Telematic communication box				A	A
Electronic transmission control				A	A
Electronic height control				A	A
Fuel-pump control				A	A
Parking brake				A	A
Rear driver seat module				A	A
Driver seat module				A	A
Footwell module				A	A
Roof function centre				A	A
Gear selector switch				A	A
Rear-lid module				A	A
Head-up display				A	A
Integrated chassis management				A	A
Vertical dynamics management				A	A
Junction-box electronics				A	A
Camera-based driver assist system				A	A
Automatic heating/air conditioning				A	A
Rear-compartment air conditioning				A	A
Instrument cluster				A	A
Dvd changer				A	A
Navigation and radio module				A	A
Engine control module				A	A
Engine control module 2				A	A
Night vision electronics				A	A
Park distance control				A	A
Tyre pressure control				A	A
Damper satellite rear left				A	A
Damper satellite rear right				A	A
Damper satellite front left				A	A
Damper satellite front right				A	A
Rear seat entertainment system				A	A
Steering column switch centre				A	A
Combox multimedia				A	A
Allround-view camera				A	A
Video module				A	A
Controller				A	A
Rear-compartment controller				A	A
Central gateway module				A	A