

**Legend**

PAR = Parameters

ATT = Check Components (active Diagnosis)

COD = Adaptation and coding

DIAG = Diagnosis

■ = Supportated

A = Self-recognition

**Smart****For Four (453)**

<b>DESCRIPTION</b>	<b>DIAG</b>	<b>DTC</b>	<b>PAR</b>	<b>ATT</b>	<b>COD</b>
Gateway collision prevention	■	■	■	■	■
SAM rear	■	■	■	■	■
Audio gateway	■	■	■	■	■
Air conditioning	■	■	■	■	■
Rear	■	■	■	■	■
Transmission control	■	■	■	■	■
SAM drive	■	■	■	■	■
Power steering	■	■	■	■	■
ESP - Electronic Stability Program - ESP453	■	■	■	■	■
Collision prevention assist	■	■	■	■	■
Instrument cluster	■	■	■	■	■
Lane assist	■	■	■	■	■
ME - Motor electronics - ME17_453	■	■	■	■	■
ME - Motor electronics - ME30	■	■	■	■	■
Display audio COMAND	■	■	■	■	■
SRS - Airbag - ORC453	■	■	■	■	■
Audio - Audio or COMAND - RO_13_453	■	■	■	■	■
Audio - Audio or COMAND - R_MID453	■	■	■	■	■
Selector module	■	■	■	■	■
Sound system	■	■	■	■	■
Telematics services	■	■	■	■	■

**For Four (454)**

<b>DESCRIPTION</b>	<b>DIAG</b>	<b>DTC</b>	<b>PAR</b>	<b>ATT</b>	<b>COD</b>
Instrument cluster	■	■	■	■	■
ABS - Electronic Stability Program	■	■	■	■	■
AB - Airbag - AIRBAG	■	■	■	■	■
CDI - Common Rail Diesel - EDG	■	■	■	■	■
Electrical Power Steering	■	■	■	■	■
ESP - Electronic Stability Program	■	■	■	■	■
Air conditioning	■	■	■	■	■
ME - Electronic motor - ME	■	■	■	■	■

Multifunction steering wheel					
SAM - SAM control Unit Version 1					
SAM - SAM control Unit Version 2					
Gateway Central ZGW					

### For Two (450)

<i>DESCRIPTION</i>	<i>DIAG</i>	<i>DTC</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Instrument cluster					
Adaptive Brake System					
Airbag Serie 1					
Airbag Serie 2					
EDG Electronic motor Diesel - EDG					
Electrical Power Steering					
Electronic Stability Program (CanBus)					
Electronic Stability Program					
Electronic motor MEG Euro 2					
Electronic motor MEG Euro 2 BRABUS					
Electronic motor MEG Euro 3					
Electronic motor MEG Euro 3 BRABUS					
Electronic motor MEG Euro 4					
Electronic motor MEG Euro 4 BRABUS					
Central Gateway 4					
Central Gateway 2					
Central Gateway 3					
Central Gateway					

### For Two (451)

<i>DESCRIPTION</i>	<i>DIAG</i>	<i>DTC</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Instrument cluster					
AB - Airbag - AIRBAG					
CDI - Common Rail Diesel - CDI					
Electrical Power Steering					
ESP - Electronic Stability Program - ESP					
Air conditioning					
ME - Electronic motor - ME					
Starter					
Gateway Central					
Sprintshift module					

### For Two (453)

<i>DESCRIPTION</i>	<i>DIAG</i>	<i>DTC</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Gateway collision prevention					
SAM rear					
Audio gateway					

Air conditioning						
Rear						
Transmission control						
SAM drive						
Power steering						
ESP - Electronic Stability Program - ESP453						
Collision prevention assist						
Instrument cluster						
Lane assist						
ME - Motor electronics - ME17_453						
ME - Motor electronics - ME30						
Display audio COMAND						
SRS - Airbag - ORC453						
Audio - Audio or COMAND - R0_13_453						
Audio - Audio or COMAND - R_MID453						
Selector module						
Sound system						
Telematics services						

## Roadster (452)

<i>DESCRIPTION</i>	<i>DIAG</i>	<i>DTC</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
AE - Restraint system - AE					
EPS control unit					
ESP - Electronic Stability Program - ESP					
Instrument cluster					
MEG - Motor electronics					
MEG - Motor electronics BRABUS					
Central gateway SAM					