



*Everything you need from tents to teaspoons*

## **Sno-Cone Machine**

We are pleased to provide to you quality equipment.

- Do not place foreign objects into the machine.
- Switch the motor to "On".
- Wait for the motor to come to full speed, approximately 2 minutes.
- Fill the gooseneck to within an inch of the top with ice cubes or block ice (chunks should be no larger than 3-4 inches). The larger the pieces the better the snow.
- Push the handle down against the ice. Apply firm and even pressure. Over pressing will cause the motor to stall. You may need to relive the pressure 2-3 times per cycle.
- The motor will become warm. A surface temperate of 150 degrees is normal.
- Use mild soapy water to clean and wipe dry.

### **Additional Information:**

SnoCone cups (pack of 50) - \$4.00

Sipper straws (pack of 50) -\$2.00

Syrup - \$8.50 per ½ gal (approx. 50 sno cones)

-Blue Raspberry

-Cherry

-Orange

-Lime

-Grape

6oz of ice per serving

20LB bag = 50 servings

You will be charged a replacement fee for items returned dirty, broken, damaged or lost.

**Please call us at 734.354.9591 with any concerns.**