

**Intermediate Maintenance Checklist – 911 Carrera/S/4/4S/Turbo/S (991) (2014-on)**

Required Maintenance and Lubrication Service

---

\* **Oil Change** Every 10,000 miles (15,000 km) or 1 year. **See Below Check Box.**

- Intermediate Maintenance** (Labor Operation 03 14 00 ..) See Technical Manual  
After 20,000, 60,000, 100,000, 140,000 miles etc. / 30,000, 90,000, 150,000, 210,000 km etc.  
**Note:** If the mileage for scheduled maintenance is not reached, intermediate maintenance must be performed no later than after 2, 6, 10..... years.

The terms 'check' and 'inspection' include all necessary subsequent work such as adjusting, readjusting, correcting and topping off, but do not include repairing, replacing and reconditioning parts or assemblies.

**Electrics**

- Diagnosis system: Read out fault memory; reset maintenance interval
- Windshield wiper/washer system, headlight washer: Check function and nozzle adjustment
- Horn: Check operation
- Tires: Check tire pressure (TPM)
- Batteries and ventilation hoses: Check condition
- Electrical equipment as well as indicator and warning lights: Check operation
- Check actuator travel of brake shoes (911 Turbo/Turbo S only)

**Inside of Vehicle**

- Pollen filter: Replace filter element

**Front Luggage Compartment**

- Pollen filter: Replace pre-filter element
- Check front lid lock and safety hook of the front lid for secure seating and function properly
- Windshield wiper/washer system, headlight washer: Check fluid level and antifreeze protection level
- Check firewall body drains for debris

**Outside of Vehicle**

- Check wiper blades
- Vehicle lighting: Check operation
- All headlights: Check adjustment
- Radiators and air intakes: Visual inspection for exterior debris and blockage
- Check the two Targa center bar drains for debris (911 Targa models only)

**Under the Vehicle**

- Drain engine oil
- Tires: Check condition
- Brake system: Visual inspection of the brake pads & brake discs for wear (w/o removing wheels) (Except PCCB)
- Vehicles with PCCB: As of MY 2014, PCCB Brake discs must be checked for wear during every service and whenever brakes pads are replaced using special tool VAS 6813. Please refer to workshop manual for work procedure.
- Brake hoses and lines: Visual inspection for damage, correct routing and corrosion Check brake fluid level
- Axle shafts: Visual inspection of the dust boots for leaks & signs of damage

**Engine Compartment**

- Change oil filter and fill engine oil (Every 10,000 miles/15,000 km, see separate Oil Change Sheet, PNA 000 162 LC)
- Coolant: Check level and antifreeze protection level
- PDCC: Check fluid level
- Check firewall body drains for debris

**Additional Maintenance – Replace Spark Plugs** (Labor Operation 03 81 00 ..)

- Replace spark plugs: every 40,000 miles / 60,000 km or 4 years (Except Turbo)
- Replace spark plugs: 911 Turbo/Turbo S every 30,000 miles / 45,000 km or 4 years

**Additional Maintenance - Drive Belt** Labor operation 03 60 00 ..

- Check drive belt at 40,000 miles (60,000 km) or every 4 years
- Check drive belt at 100,000 miles (150,000 km) or every 10 years
- Check drive belt at 160,000 miles (240,000 km) or every 16 years

**Additional Maintenance – Convertible Top** (Labor Operation 03 70 00 ..)

- Service and maintain convertible top: every 20,000 miles / 30,000 km or 2 years

**Additional Maintenance – Targa Roof** (Labor Operation 03 71 00 ..)

- Service and maintain Targa roof: every 20,000 miles / 30,000 km or 2 years
-

**Additional Maintenance every 60,000 miles / 90,000 km or 6 years** (Labor Operation 03 83 00 ..)

- Replace PDCC reservoir
- Replace drive belt
- Change all-wheel drive controller oil (4-wheel drive models only)

**Additional Maintenance every 80,000 miles / 120,000 km or 4 years** (Labor Operation 03 85 00 ..)

- Ancillary unit mounts and chassis: visual inspection of all rubber mountings and boots for damage

**Additional Maintenance every 120,000 miles / 180,000 km or 12 years** (Labor Operation 03 88 00 ..)

- Manual transmission: change oil
- PDK transmission: change oil
- PDK transmission: change clutch oil
- All-wheel final drive: change oil (4-wheel drive models only)

**Additional Maintenance every 2 years** (Labor Operation 03 51 00 ..)

- Change brake fluid (use only Original Porsche Brake Fluid)
- Tire sealant (check expiration date and replace as necessary)

Inspection Performed - Technician Signature: \_\_\_\_\_

**Road Test Check**

- Remote control, front seats, foot brake and electric parking brake (also operating travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM, PASM & Sport switches, sports exhaust system, door mirror fold-in function, heater, air-conditioning system and instruments: Check operation
- Oils, fluids: Visual inspection for leaks

Road Test Performed - Technician Signature: \_\_\_\_\_

**Customer Name:** \_\_\_\_\_

**Date:** \_\_\_\_/\_\_\_\_/\_\_\_\_

**VIN: WPO** \_\_\_\_\_

**Mileage** (check one)  **Miles**  **Kilometers:** \_\_\_\_\_

**Dealer Name:** \_\_\_\_\_

**Dealer Code:** \_\_\_\_\_

**Repair Order #:** \_\_\_\_\_

**Technician Name:** \_\_\_\_\_

**Technician Signature:** \_\_\_\_\_